

# RIMAGE CATALYST® SERIES

## Professional performance and quality in the right-sized package

Rimage Catalyst® disc publishing systems offer industrial grade hardware, front-office friendly design and professional quality disc production, an ideal choice when high-volume production is not required. The Catalyst system comes standard with an Everest® Encore™ or a Prism III™ printer and, a fit for any IT environment, can be ordered with or without an embedded PC.

## Benefits

### Powerful Printing

Catalyst systems, with the world's best full-color and thermal monochrome disc printers, provide top-of-the-line printing and industrial-grade production in a front-office friendly package.

### Rugged Durability

With positive air flow through a front-accessible filter, quick-release recorders, front-facing hard drive bays and separate printers, Catalyst systems are designed to be easily maintained in any environment.

### Flexible Production

A three-bin carousel handles up to 150 discs, either one type of disc for uninterrupted production or up to three types of discs for productive flexibility. Disc output can be configured to the external bin or one of the internal bins behind a lockable door.

## Features

- 150-disc rotating carousel for input/output
- 50-disc external output
- Embedded computer with network connectivity (on Catalyst 6000N only)
- Front accessible air filter and positive airflow
- Two line LCD status display
- Integrated DiscWatch™ status light
- Front accessible USB 3.0 port
- Internal lighting when the door is opened
- Two quick-release front-swappable recorders
- Front accessible hard drive bays
- Rimage Software Suite (RSS)
- Everest Encore printer or Prism III printer
  - Everest Encore: Best quality printer for permanent, full-color printing
  - Prism III: Fastest and lowest-cost per disc thermal monochrome printer on the market



## Options

- Blu-ray Disc™ recorders
- Your choice of Everest Encore or Prism III print technology

## SYSTEM SPECIFICATIONS

	CATALYST 6000N	CATALYST 6000
<b>Number of Recorders</b>	2	2
<b>Carousel / Total Capacity</b>	3 bins / 150 discs	
<b>External Output Bin Capacity</b>	50 discs	
<b>Printer</b>	Everest Encore or Prism III	
<b>CPU</b>	Intel Core I3-6100	User Supplied
<b>Trusted Platform Module (TPM)</b>	Included	N/A
<b>HDD Storage</b>	2 x 500 GB	User Supplied
<b>RAM</b>	8 GB	
<b>Operating System</b>	Win 10 Enterprise 64-bit	
<b>Network Adapters</b>	Two 1 GB Ethernet	
<b>Rimage Software Suite (RSS)</b>	A full set of software tools enabling unique artwork design, job submission, system management, production monitoring and custom application creation.	
<b>CD Designer™</b>	Label creation software – included	
<b>QuickDisc™</b>	Disc burning software – included	
<b>WebRSM™ / Rimage System Manager (RSM)</b>	Control and manage the system, locally or through the web – included	
<b>Height</b>	25,5 in / 64,7 cm	
<b>Width</b>	16 in / 40,6 cm	
<b>Depth*</b>	23,25 in / 59 cm	
<b>Weight (without printer)</b>	65,3 lb / 29,7 kg	61,7 lb / 28 kg
<b>Weight w/ Everest Encore</b>	109,3 lb / 49,7 kg	105,7 lb / 48 kg
<b>Weight w/ Prism III</b>	85,3 lb / 38,8 kg	81,7 lb / 37,1 kg
<b>Power Specifications</b>	100-240 VAC, 60/50 Hz, 3,9-2,6 AMP, 500 watt Maximum	
<b>Warranty</b>	12 months	

\* Allow space (3,5" or 9 cm) in rear of machine for cabling.

## We Recommend

### Rimage Maintenance Agreements

Maximize your ROI and minimize downtime when quick problem resolution is a must. With our range of skilled technicians and industry-leading support services, Rimage has a maintenance plan that meets your needs.

### Rimage Media Kits

Get reliable, uninterrupted performance from your Catalyst system. With optimized print ribbons and discs, Media Kits give you the best-looking, longest-lasting results in one convenient and affordable package.

For complete information about Rimage Catalyst Series support options and Media Kits, visit [www.rimage.com](http://www.rimage.com).

Blu-ray Disc™ is a trademark of the Blu-ray Disc Association.

